



## SICHERHEITSHINWEISE ZUR NUTZUNG IM FLUGZEUG SAFETY INSTRUCTIONS FOR USE ON AN AIRCRAFT

PRIVIA

ECE-Gruppe 0/0+ (bis 13 kg) | ECE Group 0/0+ (up to 13 kg)



### EINBAU

- Klappen Sie die Armlehnen des Flugzeug-sitzes hoch
- Die Babyschale **muss rückwärtsge-richtet** auf dem Sitz platziert werden
- Führen Sie die Flugzeuggurte durch die blauen Gurtführungen
- Schließen Sie das Gurtschloss mit einem hörbaren KLICK
- Straffen Sie den Gurt

### WICHTIG

Es dürfen keine starren Teile des Gurtes an den Gurtführungen anliegen. In diesem Fall benötigen Sie eine Gurtverlängerung der Fluggesellschaft, um die Babyschale im Flugzeug sicher befestigen zu können.

### INSTALLATION

- Fold up the armrests of the aircraft seat
- The infant carrier **must be place rearward facing** on the seat
- Run the aircraft belt through the blue guides on the infant carrier
- Close the buckle with an audible CLICK
- Tighten the belt

### IMPORTANT

No rigid parts of the aircraft belt may touch the blue guides. In this case you will need a belt extension from the airline in order to secure the infant carrier correctly.

## HINWEIS

Die Verwendung des Kindersitzes mit einem 2-Punkt-Gurt ist nur im Flugzeug zulässig.

Informieren Sie sich bei Ihrer Fluggesellschaft über die Sicherheitsbedingungen bevor Sie den Kindersitz verwenden.

Der Kindersitz darf nur auf einem von der Fluggesellschaft freigegebenen Platz installiert werden.

Zu korrekten Sicherung Ihres Kindes im Kindersitz richten Sie sich bitte nach der Anleitung für die Verwendung im Fahrzeug, die Sie im Fach an der Rückseite des Kindersitzes finden.

Der Kindersitz muss während des gesamten Fluges angeschnallt bleiben, auch wenn Sie Ihr Kind nach Erlöschen der Ansnallzeichen herausnehmen. Ein ungesicherter Kindersitz kann bei Turbulenzen oder einer Notlandung andere Passagiere verletzen.

## NOTE

The use of the child seat with a 2-point belt is only allowed on the aircraft.

Check with your airline before flying about their safety regulations and using the child seat.

The child seat must only be installed on a seat assigned by the airline.

To adapt the child seat to your child's needs, please follow the instruction manual for use in the vehicle, which can be found on the bottom side of the child seat.

During the flight, the child seat must be secured at all times, even if you take out your child when the fasten seat belt sign has been switched off. An unsecured child seat could injure other passengers in the event of turbulence or an emergency landing.

Version 06/2015

Druckfehler, Irrtümer und technische Änderungen vorbehalten.

Subject to printing errors, mistakes and technical changes.

Hersteller | Manufacturer  
RECARO Child Safety GmbH & Co. KG  
Guttenbergstrasse 2  
D-95352 Marktkeugast  
Phone: +49 9255 77-0  
Fax: +49 9255 77-13  
Email: [info@recaro-cs.com](mailto:info@recaro-cs.com)