


1

User Guide



The Rechargeable Portable Baby Rocker


Thank you for buying the Rockit portable baby rocker. It can be fitted to most prams and strollers. It gently rocks to soothe your baby to sleep and is suitable for use with children aged 0-36 months.




WARNING:
CHOKING HAZARD - Small Parts.
Keep out of reach of children.
THIS IS NOT A TOY




Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.




What's in the Box?



1 x Rechargeable Rockit



1 x Bracket



Micro USB cable

2

Safety



WARNING: THIS IS NOT A TOY

- Please read the user guide carefully and keep for future reference.
- To be assembled and used by adults only. Not to be used by persons under the age of 14.
- Only to be used on prams and strollers. Do not use on cribs, cots or car seats.
- Always ensure that strollers and prams are on a level surface and the brake is firmly applied before attaching and operating the Rockit.
- The Rockit should be positioned out of reach of the child.
- Never mount the Rockit directly above the child.
- Adult supervision required. Do not leave the child unattended.
- Charging should only be done by an adult.
- Only charge with the cable provided inserted into a USB power supply with an output rated 5V.
- Only connect to a USB power supply bearing
- The Rockit is showerproof (IPX 1). Avoid exposure to prolonged or heavy rain and ensure it is completely dry before charging.
- Regularly check that the product is firmly attached to the stroller or pram.
- Discard if the product is damaged.
- After use, remove the Rockit from the bracket and store in a safe place, out of reach of children.
- Babies are safest sleeping flat and on their backs.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Charging


Charge until the green LED glows. Only charge with the cable provided inserted into a USB power supply with an output rated 5V. After charging ensure the rubber USB cover is secured to help prevent water ingress.

3


Setting up the Rockit

Fitting the Bracket:


The Rockit bracket should be positioned out of reach of the child and fitted high up on the frame or handle.




The universal bracket fits most tube shapes.




The strap slides within the bracket so you can alter the buckle position when fitting to different sized tubes.




Ideal positioning of the bracket is on the horizontal handle. Do not position directly above the child.




You may not want to fasten the strap over an expensive leather handle as it may leave temporary marks. Alternatively it can be positioned high up on the inside of the frame.



1. Wrap strap around the tube and push the end through the slot in the buckle.




2. Tighten strap by rotating the nut clockwise until fastened. Do not over tighten. It should be just tight enough so as not to move when in use.




3. Tuck the end of the strap into the slot on the bracket.

4

Attaching the Rockit




1. Ensure the stroller or pram is on a level surface. Always apply the brake.



2. Push the Rockit clip into the bracket until it clicks. Check that it is securely mounted.

3. Rotate the Rockit until it is pointing directly upwards. This will increase the battery life and give the most effective rock.




5

Top Tips


Position the Rockit so that it doesn't protrude and get knocked when wheeling through doorways, but always make sure it is out of reach of children.

Often a slow to medium speed gives the most effective rocking motion. This also has the benefit of increasing the battery life.

Operating the Rockit



1. Press the on/off button to start or stop the Rockit. Note: The Rockit will automatically turn itself off after 1 hour.



2. Turn the speed dial to obtain the preferred gentle rocking motion. Note: We recommend using the slowest effective speed to increase battery life.

After Use

Carefully remove the Rockit from the bracket and store in a safe place, out of reach of children. Do not leave the Rockit fitted when not in use.

The bracket can be left attached to the stroller.

6

Troubleshooting

The Rockit has stopped working

The 1 hour timer automatically switches the Rockit off. Press the on/off button to restart.

The Rockit won't start, or is running very slowly



Turn up the speed dial to increase the speed. If this no longer works, recharge the battery.

The Rockit is not giving a gentle rocking motion



Adjust the speed dial to get a gentle rock (often this is achieved at a slower speed). Turning clockwise increases the speed, while anticlockwise decreases the speed.

Our Other Products

At Rockit we design innovative products to help babies and older children to sleep.



wooshh is the small but mighty sound soother. Choose from 8 sounds and 4 volume levels to find the perfect soothing environment for your baby. Its versatile design allows you to stand, clip or strap it out of reach of your baby.



Zed Soothes babies to sleep, just like the car Zed mimics the feeling of being in a car. His clever technology recreates soothing low frequency vibrations that are known to send babies to sleep. Simply place Zed on the mattress by your baby's feet and press the snooze button. The finely tuned vibrations ripple gently through the mattress, comforting your baby and encouraging a deep sleep.

7

Frequently Asked Questions

What age child can I use the Rockit with?

The Rockit is suitable for use with children from birth up until around 3 years old.

Is the rocking motion safe?

Yes. We have based the rocking motion on the way parents rock their children by hand. For more information visit www.rockitrocker.com/safety

Why is there a fast speed when the Rockit is first turned on?

This is normal and is included so that Rockit can get the weight inside spinning.

Can I use the Rockit on a cot, crib or car seat?

No. The Rockit is designed for strollers and prams only.

Why is there a 1 hour timer on the Rockit?

The Rockit is not designed to keep a child asleep for an extended period. It is meant to be a helping hand to soothe a baby and help them drift off to sleep or maintain their sleep when the stroller or pram stops.

Can the Rockit be used in the rain?

Yes, the Rockit is showerproof. (Tested to IPX1 standards). Avoid exposure to prolonged or heavy rain.

How do I clean the Rockit?

The Rockit can be surface cleaned with a damp cloth. Do not submerge in water.

Can I buy additional brackets to fit the Rockit to other pushchairs or prams?


Yes, these can be purchased from our website www.rockitrocker.com or check with your local distributor.

8

Additional Info

The Rockit was proudly designed in the UK by N2M Ltd. Discover more at www.rockitrocker.com

For customer support please visit www.rockitrocker.com/contact/



For videos showing how to set up and use the Rockit, scan the QR code or visit www.rockitrocker.com/video



[facebook.com/wearerockit](https://www.facebook.com/wearerockit)



twitter.com/wearerockit



[instagram.com/rockitrocker](https://www.instagram.com/rockitrocker)

Made in China

UK Patent GB2560984 - www.rockitrocker.com/patent


"Rockit" is a trademark of N2M Ltd, 7 Unity Street, Bristol, BS1 5HH, UK.

Rockit Europe OÜ Harju maakond, Tallinn, Kesklinna linnaosa, Tornimäe tn 5, 10145, Estonia.

Exclusive US Distributor: Pitkin Sleeps Int'l, Englewood, CO 80110 www.RockitSleep.com

For details of our trademarks and design registrations please visit: www.rockitrocker.com/IP

© 2022 N2M Ltd. All rights reserved.



9

Important



Important! Always rotate the Rockit so it points straight up.

FR

Attention! Faites tourner le Rockit jusqu'à ce qu'il pointe directement vers le haut.

IT

Attenzione! Ruotare Rockit fino a quando risulti rivolto verso l'alto.

CZ

Pozor! Otočte houpadlo Rockit tak, aby vždy směřovalo vzhůru.

NL

Aandacht! Draai de Rockit tot hij recht naar boven wijst.

DE

Aufmerksamkeit! Drehen Sie den Rockit, bis er direkt nach oben gerichtet ist.

PT

Atenção! Rode o Rockit até estar a apontar diretamente para cima.

DK

Opmærksomhed! Drej Rockit, indtil den peger direkte opad.

SE

Uppmärksamhet! Rotera Rockit tills den pekar rakt uppåt.

ES

¡Atención! Gire el Rockit a una posición vertical, es decir, mirando hacia arriba.

NO

Merk følgende! Roter Rockit inntil den peker rett oppover.